



LOADING INSTRUCTIONS

1. Feed end of roll with **out** facing labels in position (**A**).
2. Roll with **in** facing labels should be fed in position (**B**).
3. Feed down, to the right of the red bar (**C**), towards feed roller (**D**).
4. Hold the roll towards the operating handle (**E**) and close the platen assembly (**F**) followed by closing the bottom cover (**G**).